

## How to change your battery compartment lid

You only need the new lid and a coin to replace the battery lid.

1. Use a coin to open the big screw on the top upper ending of the battery compartment.



2. Open the lid completely until to its stop position.



3. At its stop position press the lid with gentle pressure further toward. The lid jumps out of its anchoring and you hear a slight click.



4. Put the new lid in with gentle pressure at both small pivots - once more you hear a slight click.

a)



b)



5. Close the lid and tighten the screw.

